

JPS

Panel

General Question



VERSION : V1.00

目錄

1. Panel 標準常見問題	2
2. PDA Panel常見問題	2
3. C Panel常見問題	2
4. R Panel常見問題	2

1. Panel 標準常見問題

2. PDA Panel 常見問題

3. C Panel 常見問題

4. R Panel 常見問題

Q01：面板顯示上看到 A0-Er 是什麼意思？

A01：近期，有些客戶發生在開機過程中時，產生 A0-Er，其原因其實是因 R-Panel 之特殊功能造成的。

若不啟動 R-Panel 的特殊功能，是不會發生的，請安心使用。

若有使用 R-Panel 的特殊功能之客戶，可依下列步驟，排除此問題：

1. 進入 J1000 且令讀取內部值=SP-OFF
2. SET J1022=1 且設定完後，請執行 RESET
3. 請重新插拔 R-Panel 或 重新開電

101. Panel General Question

102. PDA Panel General Question

103. C Panel General Question

104. R Panel General Question

Q01 : Why panel show A0-Er?

A01 : Recently, some customers during the boot process to produce A0-Er, the reason is actually caused due to special features of the R-Panel.

If you do not start the special features of the R-Panel is not going to happen, please be at ease to use.

If customers use the special features of the R-Panel, according to the following steps to eliminate this problem:

1. Access J1000 and read in the internal value = SP-OFF
2. SET J1022 = 1 set after a RESET
3. Please re-plug R-Panel or re-open electricity.



正頻企業股份有限公司
JOINT PEER SYSTEC CORP.

台北縣深坑鄉北深路 3 段 266 號 6 樓

TEL:886-2-26646866 FAX:886-2-26644889

<http://www.jps.com.tw>

E-mail:jps.service@jps.com.tw